



Knowledge Base Topic:


Modifying an Alignment Radius - Method

Software: Civil 3D 2012

1. Select radius alignment



2. When alignment is selected, select Geometry Editor Tool in Ribbon



3. Add floating lines on the end of the radius alignment

