

**461 MULTIROTATIONAL BEARINGS  
(REV 10-25-12) (FA 10-31-12) (7-13)**

ARTICLE 461-5 (Page 629) is deleted and the following substituted:

**461-5 Construction.**

Store multirotational bearings delivered to the bridge site under cover on a platform above the ground surface. Protect bearings at all times from damage and ensure they are clean, dry and free from dirt, oil, grease or other foreign substances before placement. Install the bearings in accordance with the recommendations of the manufacturer, contract drawings, and as may be directed by the Engineer. If there is any discrepancy between the recommendations of the manufacturer, these Specifications, and Contract drawings, the Engineer will be the sole judge in reconciling any such discrepancy.

Obtain the services of a qualified technical representative, employed by the manufacturer of the bearings, to supervise the first installation of each type of bearing (expansion pot, fixed pot, expansion disc, fixed disc or other type as defined by the Engineer) but for only one size of each type. Submit to the Engineer a certified statement from the manufacturer that its representative has the necessary technical experience and knowledge to supervise bearing installations and to train Contractor personnel about proper bearing installation procedures and methods. Do not install the bearings before the Engineer receives the certification and the representative is on the job site. Assume this responsibility at no further expense to the Department.