

EXPECTED IMPLEMENTATION JULY 2016

649 GALVANIZED STEEL POLES, MAST ARMS AND MONOTUBE ASSEMBLIES. (REV 10-14-15) (FA 12-27-15) (7-16)

SUBARTICLE 649-4.3 is deleted and the following substituted:

649-4.3 Painting:

649-4.3.1 General: When required by the Contract Documents, provide painted poles, mast arms and monotube assemblies. Provide products from a fabricator on the Department's list of Prequalified Fabricators of Painted Galvanized Steel Strain Poles, Mast Arms and Monotube Assemblies. Provide products that will meet specification requirements throughout the warranty period. Meet the color requirement as specified in the Contract Documents. Provide the Engineer with two metal sample coupons, a minimum of 2 inches by 4 inches, painted concurrently and with the same paint as was used on the first lot of any poles, mast arms and monotube assemblies delivered to the jobsite. Submit sample coupons and manufacturer product data sheets to the Engineer along with the delivery of the first shipment of any painted poles, mast arms or monotube assemblies delivered to the jobsite. At the time of their delivery, the sample coupons described in this paragraph shall match the color of the poles, mast arms and monotube assemblies to within 1ΔE measured as specified in 975-4. If the delivered sample coupons exhibit a difference in color from the poles, mast arms and monotube assemblies greater than 1ΔE then the sample coupons will be considered unacceptable and no payment shall be made for the materials which the sample coupons represent. Those materials shall not be accepted by the Department until acceptable representative sample coupons in accordance with the requirements of this Section have been submitted to the Engineer.

649-4.3.2 Responsible Party Warranty: When the Contract Documents call for painted galvanized steel poles, mast arms or monotube assemblies, the Contractor shall designate a responsible party to accept responsibility. The responsible party designated by the Contractor must execute and submit to the Department a form, provided by the Department, prior to the first delivery to the jobsite of any painted poles, mast arms or monotube assemblies, stipulating that the responsible party accepts responsibility for ensuring the coating system adhesion and color retention requirements as specified in 975-4 are met for a period of five years after final acceptance in accordance with 5-11. The responsible party shall also bear the continued responsibility for performing all remedial work associated with repairs of any adhesion or color retention failure as defined in Section 975, as to which notice was provided to the responsible party within the five year warranty period. Failure to timely designate the responsible party will result in the Contractor being the responsible party unless otherwise agreed to in writing by the Department. The responsible party shall be either the Contractor or the fabricator. When the responsible party is the fabricator, the responsible party shall be one of the fabricators listed on the Prequalified Fabricators of Painted Galvanized Steel Strain Poles, Mast Arms and Monotube Assemblies. This list may be viewed on the Department's website at the following URL: <http://www.dot.state.fl.us/construction/ContractorIssues/ContractorMain.shtm> .

Upon final acceptance of the Contract in accordance with 5-11, the Contractor's responsibility to ensure that the coating system adhesion and color retention requirements specified in 975-4 will terminate. The obligations of the responsible party set forth in this Section shall start at final acceptance of the Contract in accordance with 5-11 and continue thereafter until expiration of the five year warranty period.

EXPECTED IMPLEMENTATION JULY 2016

ARTICLE 649-5 is deleted and the following substituted:

649-5 Installation.

Install foundations in accordance with Section 455. Do not install poles, mast arm poles, or monotubes until the foundation has achieved 70% of the specified 28-day concrete strength and verifying test results have been submitted to the Engineer. Determine concrete strength from tests on a minimum of two test cylinders prepared and tested in accordance with ASTM C31 and ASTM C39. Before erecting the pole, clean the top of the foundation of any laitance, oils, grease or any other deleterious materials. Erect strain poles in an orientation which considering the rake and the application, cable forces will produce a plumb pole. Erect monotubes plumb at the time of installation. Plumb the pole supporting mast arms after the mast arms, traffic signals or sign panels have been placed.

If the traffic signals and/or sign panels are not in place within two working days after the mast arm is erected, furnish and install a 3 foot x 2 foot blank sign panel on the bottom of each mast arm within 6 feet of the mast arm tip and plumb the pole. Re-plumb the pole supporting mast arms after installation of traffic signals and sign panels.

Install ASTM A325 bolt, nut and washer assemblies in accordance with the following. Use bolt, nut and washer assemblies that are free of rust and corrosion and are lubricated properly as demonstrated by being able to easily hand turn the nut on the bolt thread for its entire length. Tighten nuts to a snug tight condition to bring the faying surfaces of the assembly into full contact which is referred to as snug-tight. Snug-tight is defined as the maximum nut rotation resulting from the full effort of one person using a 12 inch long wrench or equivalent. After bringing the faying surfaces to a snug-tight condition, tighten nuts in accordance with Table 460-7, Nut Rotation from the Snug Tight Condition. Maintain uniform contact pressure on the faying surfaces during snugging and turn-of-nut process, by using a bolt tightening pattern that balances the clamping force of each bolt, as closely as possible, with the equal clamping force of a companion bolt.

Base plate installation steps are as follows:

1. Verify that the nuts can be turned onto the bolts past the elevation corresponding to the bottom of each in-place leveling nut and be backed off by the effort of one person on a 12 inch long wrench, without employing a pipe extension on the wrench handle.
2. Clean and lubricate the exposed threads of all anchor bolts. Clean and lubricate the threads and bearing surfaces of all leveling nuts. Re-lubricate the exposed threads of the anchor bolts and the threads of the leveling nuts if more than 24 hours has elapsed since earlier lubrication, or if the anchor bolts and leveling nuts have become wet since they were first lubricated.
3. Turn the leveling nuts onto the anchor bolts and align the nuts to the same elevation.
4. Place structural plate washers on top of the leveling nuts; one washer corresponding to each anchor bolt.
5. Install the base plate onto the leveling nut washers, place structural plate washers on top of the base plate; one washer corresponding to each anchor bolt, and turn the top nuts onto the anchor bolts.
6. Tighten top nuts to a snug-tight condition in a star pattern. A star tightening pattern is one in which the nuts on opposite or near opposite sides of the bolt circle are

EXPECTED IMPLEMENTATION JULY 2016

successively tightened in a pattern resembling a star. For an 8 bolt circle with bolts sequentially numbered 1 to 8, tighten nuts in the following bolt order: (1, 5, 7, 3, 8, 4, 6, 2).

7. Tighten leveling nuts to a snug-tight condition in a star pattern. The distance from the bottom of the leveling nuts to the top of the concrete must not exceed one anchor bolt diameter.

8. Before final tightening of the top nuts, mark the reference position of each top nut in a snug-tight condition with a suitable marking on one flat with a corresponding reference mark on the base plate at each bolt. Then incrementally turn the top nuts using a star pattern until achieving the required nut rotation specified in Table A. Turn the nuts at least 2 full tightening cycles (passes). After tightening, verify the nut rotation. Do not exceed the Table A value by more than 20 degrees.

9. Tighten each retainer or jam nut until it is in firm contact with the top surface of the anchor bolt nut; then while preventing the anchor bolt nut from rotating, tighten the jam nut unit it is snug tight.

10. Install a screen over the gap between the base plate and foundation concrete in accordance with 649-6, or place a structural grout pad in accordance with 649-7.

Table A	
Anchor Bolt Diameter (inches)	Nut Rotation from Snug-Tight Condition
$\leq 1-1/2$	1/3 turn
$> 1-1/2$	1/6 turn

649-5.1 Camera Lowering Device Installation: Meet the requirements of 641-4.4.