

EXPECTED IMPLEMENTATION JANUARY 2015

400 CONCRETE STRUCTURES. (REV 7-14-14) (FA 7-28-14) (1-15)

SUBARTICLE 400-4 is expanded by the following new Subarticle:

400-4.4 Bridge Deck Overhang Falsework for Steel I-Girders: Locate the lower contact point of bridge deck overhang falsework supporting screed rails within 6 inches above the bottom flange. If the lower contact point of the overhang falsework bears more than 6 inches above the bottom flange and/or if the deck overhang is 4 feet or greater, submit shop drawings and calculations to the Engineer in accordance with Section 5 and Chapter 11 of the Structures Design Guidelines (SDG). The deck overhang is measured from the centerline of the girder supporting the overhang falsework to the outside edge of the concrete deck.

D

R

A

F

T